

Environment Setup Guide for Image Processing and Machine Learning

Atieh Sahraeidolatkhaneh: atieh.sahraeidolatkhaneh@hv.se

Yongcui Mi: yongcui.mi@hv.se

Overview

This guide explains how to set up a clean Python environment using Miniconda, how to launch JupyterLab each time you work, and provides a simple example at the end to help you access basic image information and perform essential image operations.

1. Python Environment Quickstart

Recommended to follow this quickstart to create a ready-to-use Conda setup. (If you already have your own Python setup, you are free to use it — just make sure you can import and run the same packages (opencv-python, numpy, matplotlib).)

1.1. Install Miniconda

Miniconda provides an isolated and reliable Python environment, preventing conflicts between different libraries.

- Visit: <https://www.anaconda.com/docs/getting-started/miniconda/install>
- Download the installer based on your system, for the computers in the lab, select **Miniconda3 Windows 64-bit**.

Note: You can follow this video: <https://www.youtube.com/watch?v=AgnAsOnPEVg>

1.2. Open Miniconda Prompt

Open the Start Menu and search for **Miniconda Prompt**. You will see:

```
1 (base) C:\Users\YourName>
```

1.3. Create a Course Environment

Creating a separate environment (e.g., *stb600*) ensures all course packages remain isolated and reproducible.

Run:

```
1 conda create -n stb600 python=3.11
```

Press **Y** when asked.

1.4. Activate the Environment

Activating the environment ensures Jupyter and Python use the correct packages.

```
1 conda activate stb600
```

You should see:

```
1 (stb600) C:\Users\YourName>
```

1.5. Install Required Libraries

Install the core packages needed for image processing and machine learning.

```
1 conda install numpy scipy matplotlib scikit-image scikit-learn
```

Install OpenCV:

```
1 pip install opencv-python opencv-contrib-python
```

Install JupyterLab:

```
1 conda install jupyterlab
```

1.6. Launching JupyterLab

Each time you start working:

1. Open Miniconda Prompt.
2. Activate the environment:

```
1 conda activate stb600
2
```

3. Move to your project folder, for example:

```
1 cd C:\Users\YourName\Documents\image_processing_course
2
```

4. Launch JupyterLab:

```
1 jupyter lab
2
```

Starting JupyterLab from the correct folder keeps notebooks and images organized.

1.7. Verify Setup

```
1 # test_setup.py
2 import sys
3 import cv2
4 import numpy as np
5 import matplotlib.pyplot as plt
6
7 print("Python version:", sys.version)
8 print("OpenCV version:", cv2.__version__)
9 print("NumPy version:", np.__version__)
10
11 # Create a simple test image (grayscale gradient)
12 img = np.linspace(0, 255, 256, dtype=np.uint8)
13 img = np.tile(img, (256, 1))
14
15 # Show image using OpenCV and Matplotlib
16 cv2.imshow("OpenCV Test Window", img)
17 cv2.waitKey(1000) # show for 1 second
18 cv2.destroyAllWindows()
19
20 plt.imshow(img, cmap='gray')
21 plt.title("Matplotlib Display Test")
22 plt.show()
23
24 print("Environment test completed successfully!")
```

1.8. Summary of Commands

```
1 # One-time installation
2 conda create -n stb600 python=3.11
3 conda activate stb600
4 conda install numpy scipy matplotlib scikit-image scikit-learn
5 pip install opencv-python opencv-contrib-python
```

```
6 conda install jupyterlab
7
8 # Each time you start working
9 conda activate stb600
10 cd <your-folder>
11 jupyter lab
```

2. Simple Example: Basic Image Operations

Below is an example demonstrating how to load, display, modify, and save an image.

```
1 import cv2
2 import numpy as np
3 import matplotlib.pyplot as plt
4
5 # Read image
6 img = cv2.imread("test.jpg")##test.jpg should be in the same folder as
   your *.ipynb file
7
8 # Check if image loaded
9 if img is None:
10     raise ValueError("Image not found. Place test.jpg in the same folder
   as your notebook.")
11
12 # Display image (convert BGR RGB)
13 plt.imshow(cv2.cvtColor(img, cv2.COLOR_BGR2RGB))
14 plt.title("Original Image")
15 plt.axis("off")
16 plt.show()
17
18 # Print image information
19 print("Image shape:", img.shape)      # (H, W, C)
20 print("Data type:", img.dtype)
21 print("Min/Max values:", img.min(), img.max())
22
23 # Take a region of interest (ROI)
24 roi = img[50:150, 100:200]
25 plt.imshow(cv2.cvtColor(roi, cv2.COLOR_BGR2RGB))
26 plt.title("ROI")
27 plt.axis("off")
```

```
28 plt.show()
29
30 # Modify pixel values: draw a red square
31 img[50:150, 50:150] = [0, 0, 255] # BGR format
32
33 # Display modified image
34 plt.imshow(cv2.cvtColor(img, cv2.COLOR_BGR2RGB))
35 plt.title("Modified Image")
36 plt.axis("off")
37 plt.show()
38
39 # Save result
40 cv2.imwrite("modified_output.jpg", img)
41 print("Saved: modified_output.jpg")
```